

## Washbasin areas

### Metropole washbasin with Vitra Fresh

---



- 7011B003-5302 Without tap hole, without overflow hole, with photocell controlled integrated electronic flusher, clou syphon included
- 7011B003-5303 Without tap hole, without overflow hole, with manuel pressured controlled integrated electronic flusher, clou syphon included



### Memoria touch-free basin mixer

---



- A47060EXP Basin mixer (mains)
- A47061EXP Basin mixer (battery)
- A47062EXP Basin tap (mains)
- A47063EXP Basin tap (battery)



### Memoria touch-free basin mixer

---



- A47064EXP Basin mixer (for bowls-mains)
- A47065EXP Basin mixer (for bowls-battery)



T4 touch-free basin mixer (mains)

---

A47068EXP

Basin mixer, mains



VitrA  
Touch-free

---

T4 touch-free basin mixer

---

A47076EXP

Basin mixer, cascade flow, mains

A47077EXP

Basin mixer, cascade flow, battery

A47078EXP

Basin tap, cascade flow, mains

A47079EXP

Basin tap, cascade flow, battery



VitrA  
Touch-free

---

T4 touch-free basin mixer

---

A47080EXP

Cascade flow, for bowls-mains

A47081EXP

Cascade flow, for bowls-battery



VitrA  
Touch-free

---

## Washbasin areas

### AquaSee built-in touch-free basin mixer

---



A47046EXP	Basin mixer (mains)
A47043EXP	Basin mixer (battery)
A47021EXP	Basin tap (mains)
A47020EXP	Basin tap (battery)



VitrA  
Touch-free

---

### Nature touch-free basin mixer

---



A47100EXP	Basin mixer (mains)
A47101EXP	Basin mixer (battery)
A4710153EXP	
A47102EXP	
A4710253EXP	
A47103EXP	
A4710353EXP	



VitrA  
Touch-free

---

### Wing touch-free basin mixer

---



A47104EXP	Basin mixer (mains)
A47105EXP	Basin mixer (battery)
A47106EXP	Basin tap (mains)
A47107EXP	Basin tap (battery)
A47104TPX	Basin mixer (for powerbox energy generator)
A47106TPX	Basin tap (for powerbox energy generator)

*A47104TPX and A47106TPX combined with A47165EXP*



VitrA  
Touch-free

---